


Table of Contents

Table of Contents	2	7. Typical applications introduced	8
1. Outlook Description	3	7.1 Chat Tool	9
2. Getting Started Guide	3	7.2 E-mail	9
2.1 Battery Charging	3	7.3 Schedule management	9
2.2 How to use SD Card	3	8. Tips and Tricks	10
2.3 Power On and Off	4	9. Personalized settings	10
2.4 Connecting to the internet	5	9.1 Wireless controls	11
3. Input operation	5	9.2 Sound and display	12
3.1 Keyboard	5	9.3 Applications	13
3.2 Touch Screen	5	9.4 SD cards and devices	13
4. Desktop	6	9.5 Date and Time	14
4.1 Status Bar	6	9.6 Locale and text	14
4.2 Shortcuts	6	9.7 About device	15
4.3 Current desktop lamp	6	9.8 Touch screen calibration	16
4.4 A quick way to add gadgets	6	10. MID locked	16
5. Web browsing	7	11. Troubleshooting	16
6. Application Management	7	11.1 Forced shutdown	16
6.1 Install and Uninstall	7	11.2 RESET	16
6.2 Software Download	8	11.3 Restore default settings	16

1. Outlook Description



2. Getting Started Guide

2.1 Battery Charging

MID has an internal charging battery. We suggest to charge up the battery when the battery power is low.

Way to Charging Battery

1. Plug in the Power adapter to Power adaptor port of device, Battery charge LED will light up. Charging procedure will be completed once the LED turns off
2. During Battery Charging, user can operate MID.

Note:

The charging time will be longer when operating and charging at same time.

2.2 How to use SD Card